
Initial Installing of Slat cleaner

Step 1: **Open the wooden package and take out the all parts**

Open the wooden box and check the items: Machine body, 1 PCS;
Handle kit, 1 set; Transpot device, 1 set; cutters, 1 set;
tool bag, 1 box; User Manual, 1 PCS; Take out all items except
the machine body.



Take out the machine body: Use the M6 socket wrench to remove
the fixing screws on the bottom plate.



励森科技



励森科技

Take out the machine body by holding the U-shaped pole and safety rope. Note: The machine is a little heavy. Pay attention to safety during lifting.



Step 2: installing the transport device

Place the machine body horizontally, then install the transport device on the bottom plate under the U-shaped handle, and rotate the locking pins aligned with the slot on the end of the plate to ensure that the pins on both sides enter the through holes on the bottom plate tightly. (Locking pins point to U-shaped pole).





After installing the transport device, place the machine UPRIGHT as shown. Note: Pay attention to safety during turning. In future, when installing the transport device next time, keep the machine UPRIGHT always to avoid any damage to the cutters.

Step 3: Installing the cutters

Open the spare parts packaging bag, take out the accessories and tools as shown, and prepare for installation.



Place stainless steel gaskets and shock-absorbing rubber ring.



Place the cutters and tighten the screws. Make sure that the cutters are tightened enough, otherwise the cutters may become loose during the cleaning slag process and it's dangerous. You can use the other SHORT terminal of the wrench to fasten the screws easily and tightly.



Step 4: installing the handle kit

Take out the Screw pole from the handle without handle head, pay attention to the MARKING on the square iron.





Insert the screw pole into the sleeve to align the nut, rotate to the right and tighten the screw pole (refer to the middle figure above) until the red marking line is flush with the port, and then push the handle into the screw.





Observe that the marking line that exposes the square iron is flush with the port, and then insert the handle with the handle head. Note: Rotate the handle properly to align the wire groove on the handle with the position of the cable.





Tighten the handle head firmly. Tighten the pipe clamp with the supplied wrench FIRMLY. Warning: Otherwise, the handle may fall off the port during processing.



Press the power cable into the groove and snap the wire into the cable clip at the end. Complete the initial assembly.

